



P320 AXG/SSG CCW Magwell Installation Instructions

Check our website at jawbonetactical.com for more info.

READ THIS SHEET IN ITS ENTIRETY BEFORE ATTEMPTING INSTALLATION.

IF YOU DAMAGE YOUR FIREARM INSTALLING THIS PRODUCT, IT IS YOUR FAULT. PERIOD. END OF STORY.

IF YOU DAMAGE THE MAGWELL WHILE INSTALLING IT, IT IS YOUR FAULT. PERIOD. END OF STORY.

We assume no responsibility for damage done to your firearm.

If you are not 100% confident you can handle this installation, please consult a competent gunsmith.

1. Make sure your gun is unloaded.
2. Also make sure it's an AXG or SXG Grip frame.
3. Place the magwell on the bottom of the grip, inserting the tab into the corresponding hole on the bottom of the frame.
4. It should be a nice snug fit, but should not take any hammering to get it on. If it comes to that, see step 2.
5. Secure in place with the provided screw (4-40 for AXG, M3 for SXG) in the hole at the back of the grip. This is a small screw! Only torque it to 10 in-lbs. If you're really nervous, use a drop of BLUE loctite.
6. The threaded hole you're screwing into is at an angle, keep this in mind. If you cross-thread this hole... tough luck. There's nothing we can do for you. You should not be screwing things into guns if you can't figure this out.
7. Make sure your mags fit before you take it to the range. Again- This is not compatible with factory magazine base plates.